FRONT VIEW
(WITH LIDS REMOVED)

TECHNOMAD
POWER AMPLIFIER

TECHNOMAD
FLASH RAM PLAYBACK UNIT

TECHNOMAD
AUDIO MIXER

FRP CD TAPE LEVEL

BASS TREB

REAR VIEW
(WITH LIDS REMOVED)

SPEAKER OUTPUTS
CHANNEL 2
CHANNEL 1